ab213906 – Rat PDGF-AB ELISA Kit

For the quantitative detection of Rat PDGF-AB in cell culture supernatants, cell lysates, tissue homogenates, serum and plasma (heparin, EDTA).

This product is for research use only and is not intended for diagnostic use.

Table of Contents

1.	Overview	1
2.	Protocol Summary	2
3.	Precautions	3
4.	Storage and Stability	3
5.	Limitations	4
6.	Materials Supplied	4
7.	Materials Required, Not Supplied	5
8.	Technical Hints	6
9.	Reagent Preparation	7
10.	Standard Preparation	9
11.	Sample Preparation and storage	10
12.	Assay Procedure	12
13.	Calculations	14
14.	Typical data	15
15.	Typical sample values	16
16.	Troubleshooting	17
17.	Notes	18

Overview

The Rat PDGF-AB Enzyme-Linked Immunosorbent Assay (ELISA) kit (ab213906) is designed for the quantitative measurement of Rat PDGF-AB in cell culture supernatants, cell lysates, tissue homogenates, serum and plasma (heparin, EDTA).

The ELISA kit is based on standard sandwich enzyme-linked immune-sorbent assay technology. A monoclonal antibody from mouse specific for PDGF-AB has been pre-coated onto 96-well plates. Standards and test samples are added to the wells; a biotinylated detection polyclonal antibody from goat specific for PDGF-AB is added subsequently and then followed by washing with 1X Wash Buffer. Avidin-Biotin-Peroxidase Complex is added and unbound conjugates are washed away with 1X Wash Buffer. HRP substrate TMB is used to visualize HRP enzymatic reaction. TMB is catalyzed by HRP to produce a blue color product that changed into yellow after adding acidic TMB Stop Solution. The density of yellow is proportional to the rat PDGF-AB amount of sample captured in plate.

The platelet-derived growth factor (PDGF) is a mitogen derived from human platelets consisting of two related polypeptides termed A and B chains. The genes for PDGF A chain, B chain/c-sis, and the PDGF receptor are expressed in human malignant glioma cell lines. Normal human endothelial cells in culture express the B chain of PDGF, and that endothelial-derived PDGF B chain is synthesized as a predicted precursor polypeptide of MW 27,281. The entire B chain of PDGF is highly (96%) homologous to a portion of p28sis, the transforming protein of simian sarcoma virus (SSV). It has been suggested that p28sis exerts its transforming potential by mimicking the growth promoting activity of PDGF and stimulating the cell in an autocrine manner. PDGF A-chain precursor polypeptide is assigned to the proximal long arm of chromosome 7, band q11.23. The human homolog (PDGF Bchain/c-sis) of the transforming gene of simian sarcoma virus is assigned to chromosome 22.

2. Protocol Summary

Prepare all reagents, samples, and standards as instructed Add 100 µL standard or sample to appropriate wells Incubate at 37°C for 90 minutes Discard plate content. Do not wash. Add 100 µL biotinylated Antibody in to all wells Incubate at 37°C for 60 minutes Wash each well three times with 300 µL 1X Wash Buffer Add 100 µL ABC working solution Incubate at 37°C for 30 minutes Wash each well five times with 300 µL 1X Wash Buffer Add 90 uL TMB Incubate at 37°C in dark for 15-20 minutes Add 100 µL TMB Stop Solution and read OD at 450 nm within 30 minutes

3. Precautions

Please read these instructions carefully prior to beginning the ELISA assay.

- All kit components have been formulated and quality control tested to function successfully as a kit.
- We understand that, occasionally, experimental protocols might need to be modified to meet unique experimental circumstances. However, we cannot guarantee the performance of the product outside the conditions detailed in this protocol booklet.
- Reagents should be treated as possible mutagens and should be handled with care and disposed of properly. Please review the Safety Datasheet (SDS) provided with the product for information on the specific components.
- Observe good laboratory practices. Gloves, lab coat, and protective eyewear should always be worn. Never pipette by mouth. Do not eat, drink or smoke in the laboratory areas.
- All biological materials should be treated as potentially hazardous and handled as such. They should be disposed of in accordance with established safety procedures.

4. Storage and Stability

Store ELISA kit at -20°C immediately upon receipt.

Refer to list of materials supplied for storage conditions of individual components. Observe the storage conditions for individual prepared components in the Materials Supplied section.

Aliquot components in working volumes before storing at the recommended temperature.

5. Limitations

- ELISA kit intended for research use only. Not for use in diagnostic procedures.
- Do not mix or substitute reagents or materials from other kit lots or vendors. Kits are QC tested as a set of components and performance cannot be guaranteed if utilized separately or substituted.

6. Materials Supplied

Item	Quantity	Storage Condition (Before prep)	Storage Condition (After prep)
Anti-rat PDGF-AB coated Microplate (12 x 8 wells)	1 x 96 well plate	-20°C	-20°C
Lyophilized recombinant Rat PDGF-AB standard	2 x 1 vial	-20°C	-20°C
Biotinylated anti-Rat PDGF-AB antibody	100 µL	-20°C	-20°C
Avidin-Biotin-Peroxidase Complex (ABC)	100 µL	-20°C	-20°C
Sample diluent buffer	30 mL	-20°C	-20°C
Antibody diluent buffer	12 mL	-20°C	-20°C
ABC diluent buffer	12 mL	-20°C	-20°C
TMB	10 mL	-20°C	-20°C
TMB Stop Solution	10 mL	-20°C	-20°C
Adhesive Plate Seal	4	-20°C	-20°C
Wash Buffer (25X)	20ml	-20°C	-20°C

7. Materials Required, Not Supplied

These materials are not included in the kit, but will be required to successfully perform this assay:

- Microplate reader capable of measuring absorbance at 450 or 600 nm.
- Automated plate washer.
- Multi- and single-channel pipettes.
- Clean tubes and Eppendorf tubes.
- Tissue homogenizer.
- Lysate Solution.
- Centrifuge.

8. Technical Hints

- Samples generating values higher than the highest standard should be further diluted in the appropriate sample dilution buffers.
- Avoid foaming or bubbles when mixing or reconstituting components.
- Avoid cross contamination of samples or reagents by changing tips between sample, standard and reagent additions.
- Ensure plates are properly sealed or covered during incubation steps.
- Do not allow 96-well plate dry, for dry plate will inactivate active components on plate.
- Complete removal of all solutions and buffers during wash steps is necessary to minimize background.
- All samples should be mixed thoroughly and gently.
- Avoid multiple freeze/thaw of samples.
- When generating positive control samples, it is advisable to change pipette tips after each step.
- Before using the Kit, spin tubes and bring down all components to the bottom of tubes.
- In order to avoid marginal effect of plate incubation due to temperature difference (reaction may be stronger in the marginal wells), it is suggested that the diluted ABC and TMB solution will be pre-warmed in 37°C for 30 minutes before using.
- Take precautionary measures to prevent operator contamination (such as saliva and other body fluids) of kit reagents while running this assay.
- To avoid high background always add samples or standards to the well before the addition of the antibody cocktail.
- This kit is sold based on number of tests. A 'test' simply refers to a single assay well. The number of wells that contain sample, control or standard will vary by product. Review the protocol completely to confirm this kit meets your requirements. Please contact our Technical Support staff with any questions.

9. Reagent Preparation

- Equilibrate all reagents to room temperature (18-25°C) prior to use. The kit contains enough reagents for 96 wells.
- Prepare only as much reagent as is needed on the day of the experiment.
- 9.1 Anti-rat PDGF-AB coated Microplate (12 x 8 wells)
 One plate of 96 wells. Ready to use. Store at -20°C.

9.2 Lyophilized recombinant Rat PDGF-AB standard (2 x 10 ng)

- 9.2.1 PDGF-AB standard solution should be prepared no more than 2 hours prior to the experiment. Two tubes of PDGF-AB standard (2 x 10 ng) are included in each kit. Use one tube for each experiment.
- 9.2.2 Add 1 mL sample diluent buffer into one tube to create 10,000 pg/mL of Rat PDGF-AB stock solution. Keep the tube at room temperature for 10 minutes and mix thoroughly.

9.3 Biotinylated anti-Rat PDGF-AB antibody The solution should be prepared no more than 2 hours prior to the experiment.

- 9.3.1 The total volume should be: 100 μ L /well x (the number of wells). (Allowing 100 μ L 200 μ L more than total volume.)
- 9.3.2 Biotinylated anti-Rat PDGF-AB antibody should be diluted in 1:100 with the antibody diluent buffer and mixed thoroughly. (i.e. Add 1 μ L Biotinylated anti-Rat PDGF-AB antibody to 99 μ L antibody diluent buffer.)

9.4 Avidin-Biotin-Peroxidase Complex (ABC) Before use, briefly centrifuge the tubes in case any of the contents are trapped in the lid or sticking to the tube walls. The solution should be prepared no more than 1 hour prior to

The solution should be prepared no more than 1 hour prior to the experiment.

- 9.4.1 The total volume should be: 100 μ L/well x (the number of wells). (Allowing 100 μ L 200 μ L more than total volume.)
- 9.4.2 Avidin-Biotin-Peroxidase Complex (ABC) should be diluted in 1:100 with the ABC dilution buffer and mixed thoroughly. (i.e. Add 1 μ L ABC to 99 μ L ABC. diluent buffer.)

9.5 Sample diluent buffer

30 mL. Ready to use. Store at -20°C.

9.6 Antibody diluent buffer

12 mL. Ready to use. Store at -20°C.

9.7 ABC diluent buffer

12 mL. Ready to use. Store at -20°C.

9.8 TMB

10 mL. Ready to use. Store at -20°C.

9.9 TMB Stop Solution

10 mL. Ready to use. Store at -20°C.

9.10 1X Wash Buffer

- 9.10.1 Prepare 500 mL of working 1X Wash Buffer by diluting 20 ml of the supplied Wash Buffer (25X) with 480 ml of deionized or distilled water.
- 9.10.2 If crystal have formed in the concentrate, warm to room temperature and mix it gently until crystals have completely dissolved.

10. Standard Preparation

- 10.1 To prepare standards, label 7 Eppendorf tubes with 2,000 pg/mL, 1,000 pg/mL, 500 pg/mL, 250 pg/mL, 125 pg/mL, 62.5 pg/mL and 31.25 pg/mL respectively.
- 10.2 Prepare 2000 pg/mL standard: add 200 µL of the above 10,000 pg/mL Rat PDGF-AB stock solution into 800 µL sample diluent buffer into 1st tube and mix.
- 10.3 Aliquot 300 μ L of the sample diluent buffer into tubes 2 to 7.
- 10.4 Add 300 µL of the above 2000 pg/mL Rat PDGF-AB into 2nd tube and mix.
- 10.5 Transfer 300 μ L from 2nd tube to 3rd tube and mix. Transfer 300 μ L from 3rd tube to 4th tube and mix, and so on.

Tube #	Volume to dilute	Volume of diluent	Concentratio n (pg/mL)
1	200 µL of 10,000 pg/mL stock solution	800 µL	2000
2	300 µL of tube #1	300 µL	1000
3	300 µL of tube #2	300 µL	500
4	300 µL of tube #3	300 µL	250
5	300 µL of tube #4	300 µL	125
6	300 µL of tube #5	300 µL	62.5
7	300 µL of tube #6	300 µL	31.25

 Δ Note: The standard solutions are best used within 2 hours. The 10,000 pg/mL standard solution should be stored at 4°C for up to 12 hours, or at -20°C for up to 48 hours. Avoid repeated freeze-thaw cycles

11. Sample Preparation and storage

Store samples to be assayed within 24 hours at 4°C. For long-term storage, aliquot and freeze samples at -20°C. Avoid repeated freeze-thaw cycles.

- Cell lysates: After sufficient splitting, there should be no obvious cell sediment. Centrifuge cell lysates at approximately 10,000 X g for 5 minutes. Collect the cell lysate supernatant, assay immediately or aliquot and store samples at -20°C.
- Serum: Allow the serum to clot in a serum separator tube (about 4 hours) at room temperature. Centrifuge at approximately 1,000 X g for 15 minutes. Analyze the serum immediately or aliquot and store samples at -20°C.
- Cell culture supernatant: Remove particulates by centrifugation, assay immediately or aliquot and store samples at -20°C.
- Plasma: Collect plasma using heparin or EDTA as an anticoagulant. Centrifuge for 15 minutes at 1500 x g within 30 minutes of collection. Assay immediately or aliquot and store samples at -20°C.
- Tissue: Put the fresh tissues into chilled physiological saline quickly, rinse several times. Take the tissues out, cut up and put them into homogenizer. Add 10 mL lysate solution to 1g tissue, then, homogenize, centrifuge and collect the supernatant. (Ultrasounding if there is dope).

Assay immediately or aliquot and store samples at -20°C.

It is recommended to estimate the concentration of the target protein in the sample and select a proper dilution factor so that the diluted target protein concentration falls near the middle of the linear regime in the standard curve. Dilute the sample using the provided diluent buffer. The following is a guideline for sample dilution. Several trials may be necessary in practice. The sample must be well mixed with the Sample diluent buffer.

- High target protein concentration (20,000 pg/mL-200,000 pg/mL). The working dilution is 1:100. i.e. Add 1 µL sample into 99 µL sample diluent buffer.
- Medium target protein concentration (2000 pg/mL-20,000 pg/mL). The working dilution is 1:10. i.e. Add 10 µL sample into
 - 90 µL sample diluent buffer.
- Low target protein concentration (31.2 pg/mL-2,000 pg/mL). The working dilution is 1:2. i.e. Add 50 μL sample to 50 μL sample diluent buffer.
- Very Low target protein concentration (0 pg/mL-31.2 pg/mL). No dilution necessary, or the working dilution is 1:2.

12. Assay Procedure

- It is recommended to assay all standards, controls and samples in duplicate.
- The ABC working solution and TMB color developing agent must be kept warm at 37°C for 30 minutes before use. When diluting samples and reagents, they must be mixed completely and evenly. Standard PDGF-AB detection curve should be prepared for each experiment. The user will decide sample dilution fold by crude estimation of PDGF-AB amount in samples.
- 12.1 Aliquot 100 µL per well of the 2,000 pg/mL, 1,000 pg/mL, 500 pg/mL, 250 pg/mL, 125 pg/mL, 62.5 pg/mL and 31.25 pg/mL Rat PDGF-AB standard solutions into the precoated 96-well plate.
- 12.2 Add 100 μL of the sample diluent buffer into the control well (Zero well).
- 12.3 Add 100 µL of each properly diluted sample of rat cell culture supernatants, cell lysates, tissue homogenates, serum or plasma (heparin, EDTA) to each empty well. See "Sample Preparation" above for details. It is recommended that each Rat PDGF-AB standard solution and each sample be measured in duplicate.
- **12.4** Seal the plate with a new adhesive cover provided and incubate at 37°C for 90 minutes.
- 12.5 Remove the cover, discard plate content, and blot the plate onto paper towels or other absorbent material. Do NOT let the wells completely dry at any time.
- 12.6 Add 100 µL of biotinylated anti-Rat PDGF-AB antibody working solution into each well, seal the plate with a new adhesive cover provided and incubate at 37°C for 60 minutes.

- Wash plate 3 times with 1X Wash Buffer, and each time let washing buffer stay in the wells for 1 minute. Discard the washing buffer and blot the plate onto paper towels or other absorbent material. (Plate Washing Method: Discard the solution in the plate without touching the side walls. Blot the plate onto paper towels or other absorbent material. Soak each well with at least 300 µL 1X Wash Buffer for 1~2 minutes. Repeat this process two additional times for a total of three washes. Note: For automated washing, aspirate all wells and wash three times with 1X Wash Buffer, overfilling wells with 1X Wash Buffer. Blot the plate onto paper towels or other absorbent material.)
- 12.8 Add 100 µL of prepared ABC working solution into each well, seal the plate with a new adhesive cover provided and incubate at 37°C for 30 minutes.
- **12.9** Wash plate 5 times with 1X Wash Buffer, and each time let washing buffer stay in the wells for 1-2 minutes. Discard the washing buffer and blot the plate onto paper towels or other absorbent material. (See Step 12.7 for plate washing method.)
- **12.10** Add 90 μ L of TMB color developing agent into each well, seal the plate with a new adhesive cover and incubate at 37°C in dark for 15-20 minutes.

Δ Note: For reference only, the optimal incubation time should be determined by end user. In addition, the shades of blue can be seen in the wells with the four most concentrated Rat PDGF-AB standard solutions; the other wells show no obvious color.

- **12.11** Add 100 µL of Stop Solution into each well. The color changes into yellow immediately.
- **12.12** Read the O.D. absorbance at 450 nm in a microplate reader within 30 minutes after adding the TMB Stop Solution.

13. Calculations

The standard curve can be plotted as the relative O.D.450 of each standard solution (Y) vs. the respective concentration of the standard solution (X). The Rat PDGF-AB concentration of the samples can be interpolated from the standard curve.

(the relative O.D.450) = (the O.D.450 of each well) – (the O.D.450 of Zero well).

 Δ **Note:** if the samples measured were diluted, multiply the dilution factor to the concentrations from interpolation to obtain the concentration before dilution.

14. Typical data

Typical standard curve – Data provided for demonstration purposes only. A new standard curve must be generated for each assay performed.

Sample	Rat PDGF-AB (pg/mL)	O.D.
1	0	0.046
2	31.2	0.178
3	62.5	0.288
4	125	0.519
5	250	0.820
6	500	1.335
7	1000	1.989
8	2000	2.426




Figure 1. Rat PDGF-AB ELISA Kit (ab213906) Standard Curve

15. Typical sample values

Sensitivity -

The biological sensitivity of the assay is <3 pg/mL.

The range is 31.2 pg/mL - 2,000 pg/mL.

Precision -

Intra-assay precision: (Precision within an assay) Three samples of known concentration were tested on one plate to assess intra-assay precision.

Sample	Number of measures	Mean (pg/mL)	Standard Deviatio n	CV%
1	16	246	14.27	5.8
2	16	632	34.76	5.5
3	16	1068	50.2	4.7

Inter-assay precision: (Precision between assays) Three samples of known concentration were tested in separate assays to assess interassay precision.

Sample	Number of assays	Mean (pg/mL)	Standard Deviatio n	CV%
1	24	275	20.35	7.4
2	24	723	45.55	6.3
3	24	1249	73.7	5.9

Specificity:

Natural and recombinant Rat PDGF-AB.

Cross-reactivity:

There is no detectable cross-reactivity with other relevant proteins.

16. Troubleshooting

Problem	Cause	Solution	
	Inaccurate Pipetting	Check Pipettes	
Poor standard curve	Improper standard dilution	Prior to opening, briefly spin the stock standard tube and dissolve the powder thoroughly by gentle mixing	
	Incubation times too brief	Ensure sufficient incubation times standard/sample incubation	
Low Signal	Inadequate reagent volumes or improper dilution	Check Pipettes and ensure correct preparation	
	Incubation times with TMB too brief	Ensure sufficient incubation time until blue color develops prior addition of TMB Stop Solution	
Large CV	Plate is insufficiently washed	Review manual for proper wash technique. If using a plate washer, check all ports for obstructions.	
	Contaminated wash buffer	Prepare fresh wash buffer	
Low sensitivity	Improper storage of the ELISA kit	All components 4°C. Keep TMB substrate solution protected from light.	

17. Notes

Technical Support

Copyright © 2024 Abcam. All Rights Reserved. The Abcam logo is a registered trademark. All information / detail is correct at time of going to print.

For all technical or commercial enquiries please go to: www.abcam.com/contactus www.abcam.cn/contactus (China) www.abcam.co.jp/contactus (Japan)